

## SUNPOW OD-MT13 / MD13 Metal Detector User Manual

---

**Introduction & Safety:** - Always read all instructions before use. - Keep away from water and moisture. - Do not use near power lines or metal fences. - Supervise children at all times.

**Box Contents:** - Metal detector unit (search coil, control box, shaft) - Armrest and strap - Batteries (if included) - User manual

**Assembly & Setup:** 1. Attach the search coil to the lower shaft. 2. Connect the lower shaft to the upper shaft. 3. Secure control box to the shaft. 4. Adjust armrest and strap for comfort. 5. Insert required batteries (typically AA or 9V as per model).

**Control Panel / Display:** - Power ON/OFF switch - Sensitivity adjustment - Discrimination / Mode selector (All Metal, Notch, Pinpoint, Memory) - LCD display showing target ID, depth, battery status

**Operating Instructions:** 1. Turn power ON. 2. Select desired detection mode. 3. Adjust sensitivity for target size and depth. 4. Sweep coil slowly over ground. 5. Listen for audio signals and watch the display for target identification. 6. Use Pinpoint mode to locate exact object location.

**Maintenance & Cleaning:** - Wipe detector with dry cloth; avoid harsh chemicals. - Do not immerse in water. - Store in cool, dry place. - Remove batteries if storing for long periods.

**Troubleshooting:** - Detector not powering: Check batteries. - False signals: Reduce sensitivity or adjust discrimination. - No response: Ensure proper assembly and connections.

**Specifications:** - Detection Modes: All Metal, Notch, Pinpoint, Memory - Power: Battery operated (check model for type) - Coil Size: Typically 7-10 inches - Weight: Approx. 2-3 lbs - Adjustable Shaft: Yes

**Warranty & Support:** - Refer to the manufacturer or vendor for warranty details. - Contact SUNPOW support for assistance with replacement parts.

---

**End of Manual**